

N

NOVOFLEX

N

NOVOFLEX

The umbrella The system



PATRON handsfree umbrella
Includes: umbrella, cover, carrying strap,
backpack mount
Order code: PATRON



PATRON Reflector set
Includes: gold, silver, sunlight, white, black foils
Each 89x60cm (31.5 x 31.5 in.)
Order code: PATRON-REFLECTOR



PATRON Tripod holder
with ball head
Order code: OPL PATRON

NOVOFLEX PATRON
handsfree



NOVOFLEX
Präzisionstechnik GmbH
Brahmsstrasse 7
87700 Memmingen
Germany
phone +49 8331 88 888
fax +49 8331 47 174
mail mail@novoflex.de
www.novoflex.de



PATRON Camouflage
tent, olive
Includes: Tent, tent
storage bag, tent pegs
Order code:
PATRON TENT OLIV





PATRON Camouflage
tent, sand
Includes: Tent, tent
storage bag, tent pegs
Order code:
PATRON TENT SAND

The umbrella

NOVOFLEX PATRON
handsfree

FIRST THERE WAS THE IDEA: An umbrella for both rain and shine. For photographers! To carry hands free... During transport and shooting! Many more ideas came to mind... A monopod... A reflector... A camouflage tent... Flexible in use... Mobile use – in every situation. As an umbrella that makes impossible images possible. With a telescoping shaft and a ball head mount for use as a monopod or simply as an extension of the photographers arm. To take pictures over barriers... For self-portraiture... Reverse the umbrella to use it as a camera stand... As a fill-in flash umbrella with sunlight, silver, gold, white and black color fabrics. As a camouflage tent, or changing tent or for weather protection. A universal all in one multi-functional umbrella: The NOVOFLEX PATRON handsfree. The “patron” of all photographers.







The umbrella


Rain or shine

NOVOFLEX PATRON
handsfree


- _ Sun umbrella and rain umbrella
- _ With shoulder strap and backpack mount for hands free transport closed or opened
- _ Sunscreen with UV factor 50+
- _ Heat protection for the photographer and his equipment



The NOVOFLEX PATRON... Thanks to the cover with strap the photographer carries the umbrella over his back hands free!



The PATRON attaches to the backpack strap. It gives protection from sun, rain and heat. Both hands are free for safe camera operation. The camera display can also be easily read in the shade.



The umbrella

The monopod

NOVOFLEX PATRON
handsfree

- _ The NOVOFLEX PATRON handsfree photo umbrella gives photographers freedom and foothold at the same moment.
- _ As an extension arm, he'll be able to shoot pictures over barriers or self-portraits from above.
- _ Turned inside out the PATRON becomes an eight legged "emergency" camera stand.
- _ Mounted to the tripod with the optionally available QPL-PATRON the PATRON offers sun and rain protection for both the camera equipment and the photographer.




The extension capability of the grip allows for flexible and comfortable operation. While seated, standing or as an extension arm for images from above.



The OctoPod: By changing the curvature of the reflecting surface a practical emergency camera stand is set up in seconds, strong enough for both point and shoot and mirrorless system cameras!



Always well protected: Mounted to a tripod the NOVOFLEX PATRON, the all-weather photo umbrella offers protection or shade for the photographer and his gear.



The umbrella


The reflector-screen

NOVOFLEX PATRON
handsfree


- _ An umbrella, with a system – Three 80x80cm (31.5 x 31.5 in) reflection foils are offered in 5 different colors – sunlight, silver, gold, white and black.
- _ Mounted to a tripod or simply holding it in your hands with the reversed reflecting surface as a shapeable reflector it is essential for filling shadows or direct or bounced flash lighting.



Bright reflective films with different color characteristics make for effective contrast enhancement, targeted light in the shadows.



Mounted to a tripod with the optionally available QPL-PATRON holder the photographer will be able to adjust the PATRON reflector screen to successfully influence contrast and color until both match the photographer's creative requirements. No need for an assistant!!! RESULT: perfectly illuminated pictures under any conceivable lighting condition.



The umbrella

The camouflage tent

NOVOFLEX PATRON
tent

- _ Two different tent versions are available within the PATRON accessory system. One for nature and one for fashion photographers. Colors: olive or sand.
- _ For easy set-up of the tent – the top end of the umbrella is hooked into the corresponding hole of the tent and then simply opened.
- _ The supplied tent pegs are used to fix the tent to the ground. The NOVOFLEX walking stick BB STOCK or the QLEG monopods or a Quadropod which also supports your camera gear is used as center column to stabilize the whole tent.



The camouflage tent is easy to set up and also very fast to break down. A tripod is used as both a camera and tent support. If used as a changing room a monopod as a support beam will be sufficient.

Versatile and convenient: The NOVOFLEX PATRON tent is available in either olive or sand, as a camouflage tent for nature photographers or as mobile changing tent for fashion shoots.